


### PRODUCT CODE

- DCM-PSW-80, box of 10 sheets, covering 80 sqft in total
- DCM-PSW-150, roll of membrane, covering 150 sqft in total



### PRODUCT DESCRIPTION

The TCNA-tested DCM-PRO Peel-and-Stick Membrane can be installed directly onto clean plywood and concrete subfloors without thinset. The patented DCM-PRO design allows for more adhesive to cable contact ultimately distributing heat faster and more evenly. There is no waiting required after installation so you can begin laying the flooring immediately. The DCM-PRO Membrane is ready to tile.

For ease, installers can cut the membrane to size, peel back the protective film, and stick the membrane directly onto a plywood or concrete subfloor. Installers can use either modified or unmodified adhesives over the membrane to suit their installation needs. The DCM-PRO Peel-and-Stick Membrane can also be covered with self-levelling mortars (SLU's) to allow installation of small format tiles and other floor types such as glue-down wood and LVT's, to be laid on top of the DCM-PRO System. The unique design of the DCM-PRO Membrane protects the cable from installation damage, reducing the risk of cable failure.

The DCM-PRO Peel-and-Stick Membrane has been successfully tested to ANSI 118.12 standards and performed well on the Robinson test (ASTM C-627). It is the highest-rated membrane for floor heating systems and the first of it's kind to adhere without the use of thinset.

### FEATURES

- Under 6mm – 1/4" thick
- Rated as Anti-Fracture membrane as tested by the TCNA against ASTM 118.12
- Installs directly to subfloor, without thinset
- Ready to tile over
- Use any adhesives or SLU's on top for flooring installations
- Highest heating outputs with DCM-PRO Cable
- Lowest running costs with 1/4" Warmup Insulation Boards (WSC-0725)
- Smart operation with Warmup Smart Thermostats;  
6IE Smart WiFi Thermostat (WSC-0921), Terra WiFi Thermostat (WSC-1021)



### APPLICATION

The DCM-PRO Peel-and-Stick Membrane can be installed directly over a clean plywood or concrete subfloor without thinset. To prevent dust and similar to impede bonding, the application of a Solvent-Free primer is highly recommended prior to sticking down the membrane. For uneven floors such as some OSB's or old subfloors with residue, the Fleece-backed "MW" membrane may be advisable.

Always follow installation instructions and shop-vac/wet-mop the subfloor for effective bonding.

The Warmup DCM-PRO Cable can be installed at various spacing to achieve the desired heat output.

### PRODUCT LISTING

#### DCM-PRO PEEL-AND-STICK MEMBRANE

Code	Description	Dimensions
DCM-PSW-80	Box of 10 sheets, covering 80 sqft in total	2'6" x 3'3" 770mm x 985mm
DCM-PSW-150	Roll of membrane, covering 150 sqft in total	46'7" x 3'3" 14,200mm x 985mm

### WARRANTY & MAINTENANCE

When installed according to the installation manual, the DCM-PRO System (DCM-PRO Cable + Peel-and-Stick Membrane) is covered by Warmup's 30-year manufacturer warranty.

### TECHNICAL SUPPORT

Warmup is available 24/7/365.

For quotes, layouts and specific technical information, contact us at:

#### Warmup USA

(888) 927-6333

us@warmup.com

#### Warmup CANADA

(888) 592-7687

ca@warmup.com

### RELATED PRODUCTS

- 6iE Smart WiFi Thermostat - see WSC-0921
- Terra WiFi Thermostat - see WSC-1021
- DCM-PRO Cable - see WSC-0704
- DCM-PRO Fleece Membrane for DCM-PRO Cable - see WSC-0705